Since 1968



User Manual

Color Door Camera DRC-40KHD




www.commax.com

COMMAX

COMMAX Co.,Ltd.

- · Thank you for purchasing COMMAX products.
- Please carefully read this User's Guide (in particular, precautions for safety) before using a product and follow instructions to use a product exactly.
- The company is not responsible for any safety accidents caused by abnormal operation of the product.






1. Match the fix the whole in the wall and the fixing fixing bracket [FIG.1]

2. Wiring and Installation

- 2. Match and connect monitor line as shown below [FIG.2] (#1: Audio, #2: GND, #3: DC12V, #4: Video)
- 3. Adjust camera location on the wall by checking the image on monitor screen and fix its location
- 4. Connect the Door Release Connection Line as shown below [FIG.2]
- 5. Tighten a screw at the bottom side of the camera [FIG.1]















M3X8 (1EA)

Camera Fixing Screw



T4X18 (2EA) Bracket Fixing Screw

Connector

4PX200

MANER Monual

 \cap

Volume Sheet

4. Specification

Model No.	DRC-40KHD	
Power Consumption	DC 12V (Supplied from monitor)	
Wiring	4 wires to a monitor (polarity)	
(Main Unit /Door Release)	2 wires to the door release (non-polarity)	
Sensor Type	'CMOS 1.3 MegaPixel(AHD)'	
Video Format	NTSC or PAL STANDARD.	
Communication	Simultaneous communication	
Minimum Illumination	0.1Lux (within 300mm / LED On)	
LED	Embedded night LED (activated at night)	
Effective Viewing Angle	112°	
Angle Adjustment	Up, down 12 Degrees	
Operating Temperature	-10 °C(tested up to -40°C) ~ +40 °C	
Weight (g)	400g	
Dimension (mm)	96(W) x 155(H) x 32.5(D)	
Distance between a door camera and monitor(Resistance under 10Ω per 100	Ø 0.5 UTP	
meters on UTP Cat 5e.)	28 meters	
Warranty Period	1 year	
Environment Condition	Environment Condition	-40 °C to 50 °C
	Distance between a door	Less than 90 %
Product Life-Cycle	10 years	



COMMAX Co., Ltd.

513-11, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, Korea Int'l Business Dept. : Tel.; +82-31-7393-540~550 Fax.; +82-31-745-2133 Web site : www.commax.com

PM1040K00010

Printed In Korea / 2016.04.105